



1	01.073 Actuator, H	19	01.070 Ring, HD Brass sealing	<b>Kits</b>
2	01.068 Actuator, HD	20	01.131 Ring, HK	22, 19, 2, 9 - 01.166 Kit, HDU Pushbutton-assembled
3	03.245 Actuator, HK	21	01.169 Screw, Handle	22, 19, 2, 10 - 01.167 Kit, HDV Pushbutton-assembled
4	01.075 Adapter, Twist shaft	22	01.069 Seal, Rubber HD Flush/Sealed	
5a	01.078 Base, Handle VCSO MI	23	03.499 Shaft Adapter, VNSO Pushdown	
5b	01.170 Base, Handle VNSO MI	24	01.064 Spacer, "T" VNSO	
6	01.134 Bushing, Boot MI (new)	25	03.501 Spacer, MI, VNSO	
7	01.061 Bushing, Handle	26	01.060 Spacer, Handle	
8	01.072 Cap, H Pushbutton	27	01.077 Spring, Mech Interlock	
9	01.071 Cap, HD (Flush)	28	01.042 Spring, Twist	
10	01.071.1 Cap, HDV (recessed)	29a	03.141.2 Tube, MI VNSO in Steel Yoke	
11	03.504 Cap, HK	29b	01.116 Tube, MI-CSO in Yoke	
12	03.415 Cap, Lower "T"	30a	03.141 Tube, MI VNSO in Gate	
13	01.062 Cap, Lower Normal	30b	01.163 Tube, MI-CSO in Gate	
14	01.067 Cap, Normal	31	01.063.1 Washer, Handle	
15	01.074 Cap, Twist			
16	01.107 Clip, E-Mech Interlock			
17a	01.080 Collar, Operating-MI(newstyle)			
17b	01.079 Collar, Operating-MI(oldstyle)			
18	01.063 Nut, Jam			

THIS SPARE PARTS DRAWING IS A GENERIC REPRESENTATION OF A CUSTOM ENGINEERED PRODUCT, THEREFORE, ALL PARTS MAY NOT BE SHOWN. J.R. MERRITT CONTROLS REQUIRES THE ORIGINAL 101.XXXX DRAWING TO CORRECTLY IDENTIFY AND SUPPLY A PART TO A SPECIFIC CONTROLLER.